Push Alarm Notification Instruction Guide

The Push Alarm Notification is designed especially for mobile device. If Push Alarm Notification is enabled and alarm is triggered, the mobile device will be notified (similar to SMS) immediately. Then, the user may select the alarm notification, and tap on "OK" to run the mobile app and play the alarm video.

1. DVR/NVR setup:

In **Network Setup**, press **ENTER** to call up **Notification Setup**, and then check to enable **Push Alarm** as shown.

SMTP Server	msa.hinet.net
SMTP Port	25
Authentication	
Username	
Password	
Mail From	
Mail To #1	
Mail To #2	
Mail To #3	
Mail To #4	
Mail To #5	
Attachment	N/A

In Alarm Setup , press $\blacktriangle \lor \checkmark \lor \lor$ to change the highlighted option to Notification, and then press ENTER to enable the notification for the designated alarm.

	Alar	m Setup		8
Alarm In	1 -+	2	3	4
Normal State	Open	Open	Open	Open
Title	AI01	AI02	AI03	AI04
Delay	0 Sec.	0 Sec.	0 Sec.	0 Sec.
Focus Camera	1	2	3	4
Duration	10 Sec.	10 Sec.	10 Sec.	10 Sec.
Goto Preset	N/A	N/A	N/A	N/A
Pre-record	5 Sec.	5 Sec.	5 Sec.	5 Sec.
Post-record	10 Sec.	10 Sec.	10 Sec.	10 Sec.
Alarm Out	N/A	N/A	N/A	N/A
Buzzer	1	1	1	1
Log		1	1251	
Screen Message		1		
Notification				
FIP	-		-	-

2.	Mobile	Phone/Pad	setup
		1 110110/1 44	Jetup

Please make sure the mobile app has been installed and setup correctly for the correspondent DVR/NVR.

Please run the mobile app, and the **Device List** display will be shown.

In Device List display, if a DVR is connected, the

V T

icon will be shown on the left; otherwise,

the icon will be shown.

** For older iPhone OS, if there's problem for network connection, please run Safari first to enable network connection, close Safari, and then run the mobile app again.

In Device List, tap the device name, and the split-window display of the corresponding device will be shown. In split-window display for Landscape mode, users may tap on the top/bottom area to show the operable icons.

Tap the button to display the "Alarm I/O" dialog.

Tap the Notification switch to **ON** alarm notification of the mobile app.







0 💿 🕲

an the 🚺 hutte

For iPhone/iPad, please enable the notification for the mobile app in iPhone/iPad's Setting->Notifications->mobile app as shown.



3. Mobile Phone/Pad operations

Please note that if Alarm Notification is enabled as described above and alarm is triggered, the mobile device will be notified immediately. The user may select the alarm notification as shown below, and then tap on "Launch" or "OK" to run the mobile app and play the alarm video.

iPhone/iPad:



Android phone/tablet

